

## Montageanleitung Soft-Stopp

Art.Nr.: 016211.7046

für Magic-Corner (Seite 1) und Tandem (Seite 2)

### Magic-Corner

für Beschlag Art.Nr.:

016203 ....

016204 ....

016209 ....

016210 ....



## Montageanleitung Soft-Stopp Art.Nr.:016211.7046

für Tandem (Seite 2) und Magic-Corner (Seite 1)

### Tandem

für Beschlag Art.Nr.:

- 003430 ....
- 003432 ....
- 003435 ....
- 003437 ....
- 003440 ....
- 003442 ....

